


Alcatel 2045X - Getting Started



Keys and connectors



- Press to go left/right/up/down
 - Press to confirm an option
- Left softkey
 - Unlock keypad
 - Access main menu
- Send key
 - Pick up/Send a call
 - Press: Enter Call log
- Right softkey
 - Access contacts
 - Press: End a call
 - Return to the Home screen
 - Press and hold: Power on/off
 - Press and hold: Access your voicemail
- From home screen
 - Press: 0
 - Press and hold: "+/P/W"
- In Edit mode
 - Press: space
 - Press and hold: 0
- From Idle screen
 - Press: *
- In Edit mode:
 - Press: Access symbols table
 - Press and hold: Change input methods
- From Idle screen
 - Press: #
 - Press and hold: Activate/deactivate the Meeting mode
- In Edit mode
 - Press: Change input methods

Status Bar Icons

- Battery charge level.**
- Vibrate alert:** your phone vibrates, but does not ring or beep with the exception of the alarm.
- Bluetooth status (Activated).**
- Bluetooth status (Connected to an audio device).**
- Headset connected.**
- Keypad locked.**
- Call forwarding activated:** your calls are forwarded.
- Alarm or appointments programmed.**
- Level of network reception.**
- Voicemail message arrived.**
- Missed calls.**
- Roaming.**
- GPRS connection status (Activated).**
- GPRS connecting.**
- Music activated.**
- MMS receipt in progress.**
- Sending an MMS.**
- Silence mode:** your phone does not ring, beep or vibrate with the exception of the alarm.
- SMS unread.**
- MMS unread.**
- (Flickering) Message list is full:** your phone cannot accept any new messages. You must access the message list and delete at least one message on your SIM card.