


## CAT S50 – Insert Sim



1. Open the memory/SIM card slot cover.
2. Insert the SIM card as shown.



### Note:

- The gold contacts must be facing down on the micro SIM card with the cut off corner on the top left. Insert the micro SIM card into slot until you hear a locking sound.
- To remove the micro SIM card, press the SIM card inwards and release quickly and draw the card out to remove.
- Do not force the micro SIM card as this could damage the memory card or slot.·
- This device does not support Nano SIM card.