


Moto G4 – Insert Sim Card

Take off the back cover.


1. Turn your phone upside down. Put your fingernail in the notch on the bottom corner.
2. Press your thumb in the centre of the back cover.
3. Pry the cover off.



Remove the battery.



Put in the SIM & optional memory cards.



1. SIM 1
2. SIM 2
3. microSD (optional)


microSD



Micro SIM

Put in the optional memory card.

**micro
SD**
microSD
(optional)



Charge up & power on.



Note: fully charge your phone before using it.



Press & hold Power until the screen lights up.