

Moto G4 – Insert Sim Card

Remove the back cover and battery



To insert SIM and memory cards, remove the back cover.

Note: don't use tools to remove the cover; doing so may damage your phone.



Insert the sim card; your phone may support using two SIM cards. To insert your SIM card(s) or an optional microSD memory card, follow these instructions.

Caution: make sure you use the correct size SIM cards and don't cut the SIM cards. Don't use tools to remove the battery – doing so may damage your phone.



* **Note:** To remove SIM1, slide the lever on the slot.

Put the back cover on.

Charge your phone fully and turn the power on.

Then select your language and follow the screen prompts to get started.

