





Samsung Galaxy XCover 3 - How to insert your sim card

Open the back cover



Insert sim card with
gold part facing down



If you needed a new sim card, you will have received a triple sim card pack.

You'll need to pop out the appropriate sim card that is needed for your Samsung Galaxy XCover 3.



Mini-SIM



Micro SIM



Nano Sim

Samsung Galaxy XCover 3 uses a Micro sim card.