

Doro 6520 – Getting Started



The items supplied with your phone may vary depending on the software and accessories available in your region or offered by your service provider. You can obtain additional accessories from your local Doro dealer.

The supplied accessories provide the best performance with your phone;

1. Earpiece
2. Left selection button
3. Call button
4. Speed dials
5. Voice mail
6. Keypad lock
7. Silent/Input method
8. Microphone
9. Torch shortcut
10. Message shortcut
11. End call/Power on/off
12. Arrow buttons
13. Right selection button
14. Charging socket
15. Headset socket
16. Loudspeaker
17. Assistance button
18. Battery cover
19. Lanyard hold (lanyard is not included)

