

Doro 6520 – Getting Started



The items supplied with your phone may vary depending on the software and accessories available in your region or offered by your service provider. You can obtain additional accessories from your local Doro dealer.

The supplied accessories provide the best performance with your phone;

1. Earpiece
2. Headset socket
3. Charging socket
4. Left selection button
5. Call button
6. Speed dial A
7. Speed dial B
8. Voice mail
9. Microphone
10. International prefix/Symbols
11. Strap mount eyelet (strap not included)
12. Input method/Silent
13. Camera shortcut
14. Message shortcut
15. End call/Power on/off
16. Arrow buttons/Navigation buttons
17. Right selection button
18. Volume control
19. Red light = Battery level low/charging
20. Green light = New message/Missed call
21. Second microphone
22. Camera lens
23. Assistance button
24. Loudspeaker
25. Charging stand
26. Strap mount eyelet (strap not included)

