



To turn on your device

It is recommended to charge the battery for at least 30 minutes before you turn on your device for the first time. If using wired charging it is important to use the USB Type-C™ cable (provided), as other types of USB cables can damage your device.

1. Long press the power key until the device vibrates.
2. Enter your SIM card PIN if requested, then tap Accept icon.
3. Wait a moment for the device to start.


Your SIM card PIN is initially supplied by your network operator, but you can change it later from the Settings menu. To correct a mistake made while entering your SIM card PIN, tap Delete text icon.

To turn off your device

1. Long press the power key until the Options menu opens.
2. In the Options menu, tap Power off. It may take a while for the device to shut down.

Home Screen

To go to the Home Screen press .



The Home screen is the starting point for using your device. It's similar to the desktop on a computer screen. The number of Home screen panes is represented by a series of dots at the lower part of the Home screen. The highlighted dot shows the pane that is currently displayed.

You can add new panes to your Home screen (up to a maximum of twenty panes) and delete panes. You can also set the pane that you want to use as the main Home screen pane.

Home screen settings; You can use the Settings shortcut to adjust some basic Home screen settings. For example, you can adjust the size of icons on your Home screen.

The Application screen, which you open from the Home screen, contains the applications that come pre-installed on your device as well as applications that you download.

Widgets - widgets are small applications that you can use directly on your Home screen. They also function as shortcuts. For example, the Weather widget allows you to see basic weather information directly on your Home screen. When you tap the widget, the full Weather application opens. You can download additional widgets from Google Play.