

Moto G5 – Getting Started

The Home screen is what you see when you first turn on your phone. From here you can explore apps and more.

Note: software updates happen frequently, so your screen may look a little different than the one shown here.



Tips and tricks

- Open app list: swipe up \wedge , then swipe up to scroll through apps.
- **Return:** to return to the Home screen from any location, tap Home **O**. If One-button nav is turned on, tap the fingerprint sensor to return Home
- Pages: to add a page, drag an app to the right side of the screen until you see a white bar. You can add multiple pages. To see other pages of shortcuts and widgets (if available), swipe the Home screen left
- **Settings:** to quickly open common settings, swipe the status bar down with two fingers. To open more settings, Tap
- **Shortcuts:** swipe up , touch and hold an app, then drag it to one of the Home screen pages. To see all your apps, swipe up
- **Apps:** to remove an app from a Home screen page, touch and hold the app, then drag it to **X Remove**. (The app isn't removed from your phone, just the Home screen)
- To uninstall apps from your Home screen, touch and hold the app, then drag it to Uninstall